

FAQs

➤ [How do I set a schedule type?](#)

➤ [How do I enable/disable early start?](#)

➤ [How do I display temperature in Fahrenheit or Celsius?](#)

➤ [How do I set a temperature offset?](#)

➤ [How do I turn on/off continuous backlight?](#)

➤ [How do I set an air filter reminder?](#)

➤ [How do I set auto-changeover?](#)

➤ [How do I lock/unlock the thermostat keypad?](#)

➤ [How do I adjust the heat cycle rate?](#)

➤ [How do I adjust the aux cycle rate?](#)

➤ [How do I adjust the cool cycle rate?](#)

➤ [How do I set compressor lockout?](#)

➤ [How do I set a max heat limit?](#)

➤ [How do I set a min cool limit?](#)

➤ [How do I reset my thermostat?](#)

How do I set a schedule type? [⤴]

The thermostat has 3 different schedule types: 7-Day, 5-1-1 Day, and Non-Programmable.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“01”** displayed in the top right corner.
- Use **▲** and **▼** buttons to between
 - **7** – Allows separate program for each day
 - **5** – Allows one program for the weekdays and separate program for the weekend days
 - **0** – No Program
- Press **Exit** to save and exit when finished.

How do I enable/disable early start? [⤴]

By default, your thermostat starts heating or cooling at the scheduled time. It can start early so your programmed temperature is reached by the scheduled time.

To set early start:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“02”** displayed in the top right corner.
- Use **▲** and **▼** buttons to set early start to **ON** or **OFF**
- Press **Exit** to save and exit when finished.

How do I display temperature in Fahrenheit or Celsius? [⤴]

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“03”** displayed in the top right corner.
- Use **▲** and **▼** buttons to set early start to **°F** or **°C**
- Press **Exit** to save and exit when finished.

How do I set a temperature offset? [⤴]

Temperature offset enables your thermostat to read higher or lower than the actual temperature.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“04”** displayed in the top right corner.
- Use **▲** and **▼** buttons to set early start to **-5** to **5** degrees
- Press **Exit** to save and exit when finished.

How do I turn on/off continuous backlight? [⤴]

Your thermostat needs a **“C”** wire to enable continuous backlight.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“05”** displayed in the top right corner and **“dL”** in the center.
- Use **▲** and **▼** buttons to select
 - **ON** – continuous backlight
 - **OFF** – momentary backlight
- Press **Exit** to save and exit when finished.

How do I set an air filter reminder? [⤴]

You can set a reminder at a monthly interval. For example, 03 means to remind you every 3 months.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“06”** displayed in the top right corner.
- Use **▲** and **▼** buttons to select between **1** to **12**, or set it to **OFF** to turn off reminder.
- Press **Exit** to save and exit when finished.

How do I set auto-changeover? [⤴]

Your thermostat can automatically switches between heat and cool.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“07”** displayed in the top right corner.
- Use **▲** and **▼** buttons to set auto changeover **ON** or **OFF**.
- Press **Exit** to save and exit when finished.

How do I lock/unlock the thermostat keypad? [⤴]

You can lock keypad to prevent unwanted changes to the thermostat.

To make change:

- While at home screen, press **Menu** button.
- Use **▲** and **▼** buttons to navigate to **Settings**. Press **Menu to Enter**.
- Use **Next** and **Back** to navigate to the screen that has **“07”** displayed in the top right corner.
- Use **▲** and **▼** buttons to set lockout to **ON**.
- Press **Exit** to save and exit when finished.

To unlock keypad:

- While at home screen, press hold **Menu** and **▲** until **🔒** appears in top left corner.

How do I adjust the heat cycle rate? [⤴]

Heat cycle rate determines how often the heating system will turn on.

To make change:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“30”** displayed in the top right corner and **“CR”** in the center.
- Use **▲** and **▼** buttons to select between **FAS**, **MED** and **SLO** (Fast, Medium, Slow).
- Press **Exit** to save and exit when finished.

How do I adjust the aux cycle rate? [⤴]

Aux cycle rate determines how often your auxiliary heat will turn on. It only applies if you have a heat pump.

To adjust aux cycle rate:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“32”** displayed in the top right corner and **“CR”** in the center.
- Use **▲** and **▼** buttons to select between **FAS**, **MED** and **SLO** (Fast, Medium, Slow).
- Press **Exit** to save and exit when finished.

How do I adjust the cool cycle rate? [⤴]

Cool cycle rate determines how often your cooling system will turn on.

To adjust cool cycle rate:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“35”** displayed in the top right corner and **“CR”** in the center.
- Use **▲** and **▼** buttons to select between **FAS**, **MED** and **SLO** (Fast, Medium, Slow).
- Press **Exit** to save and exit when finished.

How do I set compressor lockout? [⤴]

The lockout protects the compressor from short cycling.

To make change:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“50”** displayed in the top right corner and **“CL”** in the center.
- Use **▲** and **▼** buttons to select between
 - **ON** – enable 5 minute delay
 - **Off** – no delay
- Press **Exit** to save and exit when finished.

How do I set a max heat limit? [⤴]

Max heat limit is the maximum set point for heat mode. It prevents your room from being overheated.

To make change:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“65”** displayed in the top right corner.
- Use **▲** and **▼** buttons to select from **47** to **99**
- Press **Exit** to save and exit when finished.

How do I set a min cool limit? [⤴]

Min cool limit is the minimum set point for cool mode. It prevents your room from being overcooled.

To make change:

- While at home screen, hold down the **Menu** button for eight (8) seconds to launch configuration menu. Don't release until your screen displays **05** in the top right corner.
- Use **Next** and **Back** to navigate to the screen that has **“66”** displayed in the top right corner.
- Use **▲** and **▼** buttons to select from **45** to **97**
- Press **Exit** to save and exit when finished.

How do I reset my thermostat? [⤴]

To conveniently reset only the schedule and user settings back to factory defaults, press **Menu** and **Backlight** buttons at the same time and hold until the display goes blank and resets.

If the thermostat has good batteries, but has a blank display or does not respond to key presses, the thermostat should be reset by **removing the batteries for 2 minutes**. This reset will not change the thermostat settings or program. If the condition persists after reinstalling the batteries, replace the thermostat.